



FIG. 9.1 Plot of voltage vs. current for a typical superconductor, showing regions of negligible resistance, the highly nonlinear critical-current regime, and the quench point where thermal runaway occurs.